

# BRIGHT ECO

## CHLORINATED DISHWASHER DETERGENT

BRIGHT ECO is a chlorinated liquid, alkaline detergent for mechanic washing in tunnel dishwashers or basket dishwashers. BRIGHT ECO is a caustic product specially used in case of particularly visible dirty residues.

BRIGHT ECO contains water softeners, padding agents and free chlorine that has an effective sanitizing action during the washing cycle and preferably it should be used with automated electronic dispensers, allowing an accurate control. BRIGHT ECO can safely be used on pots, cutlery, etc. It must not be used on aluminum.



## INSTRUCTIONS FOR USE

Generally BRIGHT ECO is mixed 2 - 5 ml per litre depending on intensity of dirt, hardness of the water and the speed of the washing chain.

BRIGHT ECO can be used with medium-hard water\*.

The temperature in the tunnel must be kept at 45-55 °C and checked through a thermostat. It is important to check and calibrate the thermometer, in order to maintain the correct temperature.

The contact time of flatware and cutlery in the washing area must be 30 seconds at least, and the set-up of the spray nozzles must be periodically checked in order to ensure 100% of surface coverage and to control if possible obstructions cause inferior performance. Depending on washing frequency, monthly descale the dishwasher with SCALEOFF.

## SHELF LIFE AND PACKAGING

12 months , 12 kg/pail and 25 kg/pail

## PRECAUTIONS

Please refer to the Material Safety Data Sheet.

* Hardness	mg/L as CaCO <sub>3</sub>
Soft	0-75
Moderate	75-150
Hard	150-300
Very Hard	> 300